


# PARTS LIST

When ordering parts include the complete unit model number listed on the unit rating plate.

## Heatstar • Large Unit Heater • Model # HSU200NG / HSU250NG / HSU300NG/ HSU400NG



### Liquid Propane to Natural Gas Conversion Kit

HSU200NG.....	F260165
HSU250NG.....	F260166
HSU300NG.....	F260167
HSU400NG.....	F260168

### Natural Gas to Liquid Propane Conversion Kit

HSU200NG.....	F260169
HSU250NG.....	F260170
HSU300NG.....	F260171
HSU400NG.....	F260172

## PARTS LIST

### SEE BACK PAGE FOR PARTS ORDERING INFORMATION

REF #	Description	200NG	250NG	300NG	400NG
1	HEAT EXCHANGER	60267	60268	60269	60270
2	UPPER SIDE PANEL	60271	60271	60271	60271
3	LATERAL SIDE PANEL 1	60272	60272	60273	60274
4	LOUVER	60275	60275	60275	60275
5	LATERAL SIDE PANEL 2	60276	60276	60277	60278
6	DOOR PANEL	60279	60279	60280	60281
7	BACK SIDE PANEL	60282	60283	60284	60285
8	BLOWER	60286	60286	60287	60287
9	WIRING CONNECTION BOX	N/A	N/A	N/A	N/A
10	THERMOSTAT TERMINAL	N/A	N/A	N/A	N/A
11	ANTI-VIBRATION SUPPORTS	N/A	N/A	N/A	N/A
12	STRAIN RELIEF	N/A	N/A	N/A	N/A
13	BURNER BOX	N/A	N/A	N/A	N/A
14	BURNERS SUPPORT BRACKET	N/A	N/A	N/A	N/A
15	INSHOT BURNER	60288	60288	60288	60288
16	ELECTRICAL COMPONENTS SUPPORT PANEL	N/A	N/A	N/A	N/A
17	IGNITER ELECTRODE	60289	60289	60289	60289
18	TRANSFORMER 120-24	60290	60290	60290	60290
19	PCB CONTROL BOARD	60291	60291	60291	60291
20	BLOWER DRIVE RELAY	60292	60292	60292	60292
21	PRESSURE SWITCH	60293	60294	60294	60294
22	DETECTION ELECTRODE	60295	60295	60295	60295
23	MANUAL RESET SAFETY THERMOSTAT (140°C)	60296	60296	60296	60296
24	AUTOMATIC SAFETY THERMOSTAT (NC 60°C)	60297	60297	60297	60297
25	BLOWER AUT. THERMOSTAT (NO 35°C)	60298	60298	60298	60298
26	ORIFICE NG	60299	60299	60300	60300
27	MANIFOLD	60301	60302	60303	60304
28	GAS VALVE 1/2" FLANGE	60305	60305	60305	60305
29	GAS VALVE	60306	60306	60306	60306
30	INLET 1/2" GAS PIPE CONNECTION	N/A	N/A	N/A	N/A
31	GAS PIPE PROTECTION	N/A	N/A	N/A	N/A
32	TURBOLATOR	N/A	N/A	N/A	N/A
33	TURBOLATOR ROD	N/A	N/A	N/A	N/A
34	ROD STOPPER	N/A	N/A	N/A	N/A
35	FLUE BOX GASKET	60307	60307	60308	60309
36	FLUE BOX	N/A	N/A	N/A	N/A
37	INDUCER GASKET	60310	60310	60310	60310
38	INDUCER	60311	60312	60312	60312
39	DOOR HINGE	60313	60313	60313	60313
40	LOUVER SPRING	60314	60314	60314	60314
41	CAPACITOR	60340	60340	60341	60341
*	ORIFICE LP	60315	60315	60316	60316
*	PRESSURE SWITCH SILICONE PIPE	60317	60317	60317	60317
*	ELECTRICAL WIRING	60318	60318	60318	60318
*	GAS VALVE CONNECTION	60319	60319	60319	60319

\*NOT SHOWN