


NEVER LEAVE THE HEATER UNATTENDED WHILE BURNING!

HS4000 IDG




NEVER LEAVE THE HEATER UNATTENDED WHILE BURNING!

REF#	P/N	ALT#	DESCRIPTION
01	50476	G06185-9010	Outlet cone
02	50498	G6290	Combustion chamber
03	50477	G06187	Insulating panel
04	50478	G06188-9010	Upper body
05	50479	G06189-9010	Inspection panel
06	40531	G06429-9010	Base
07	50338	E10695-110	Motor
08	50473	E11242	Capacitor disjuncter
09	50480	G06191	Motor support bracket
10	50339	T10267	Fan
11	50513	M20207	Washer
12	50481	G06192-9010	Air Conveyor
13	50517	P30151	Inlet Grill
14	50429	I31131	Straight Connection 4"
16	40501	I40335	Silicone,Pipe 4X8
17	50326	PH.0020201	Electrode,Ignition
20		G02084	H.T. Cable Connect
21	50492	G06280	Blast Tube
22	50510	I40804	Air,Duct,l=220mm
23	50087	E50104	Thermostat,Fan
24	50085	E50102	Switch,High,Limit
25	50173	M20107	Washer
26	50483	G06196	Bracket,fan,thermostat
27	50515	M20413	Thermostat,bulb,support
28	50524	E50767	Thermostat
29	50500	I20326	Coupler,Connection,3/4"FF
30	50507	I39106	Gas,Tube
32	50467	O2AC535	Air,intake
35	50470	C30376	Cable,Protection,36mm
36		G06449-9010	Base
37	50482	G06193	Air,Adjustment,Panel
38	50488	G06204	Air, Adjustment, Holder
39		G06460-3001	Gas Valve Support Bracket
40	50453	C30323	Cable Protection
41	50064	G06068-9005	Power Cord Support
42	N/A	G00333	Control Box
43	50077	P50127	Cover, Controls, Assembly
45	50497	G06289	ELECTRICAL, DRAWER
46	50093	E20508	FUSE,HOLDER
47	40508	E10324	FUSE 25A
49	N/A	E20319	Ground terminal board
50	50731	E20305	Terminal, Board,12-pin
51		E10938	H.T. Transformer
52		E40234	Flame Control Box

REF#	P/N	ALT#	DESCRIPTION
53		G06073	Support Plate
56	50325	E20418	Button, Stop, Protection
57	50013	E10102-P	Switch, Push button
58	50012	E20640	Receiver, Thermostat
59	50474	E20675	Plate, Plug, 90°
60	50471	E11032	Lamp
61	N/A	E30443-1	Power cord
62	50008	E11030	Lamp 120V
63	50502	I31040	Nut,3/4"
64	50512	M20130	Washer, 28x40x2mm
65	50494	G06284	Burner, Flange,102mm
66		PH.0020211	Fitting
67		PH.0020203-ZN	Air Flap
68	50514	M20315	Seeger, Ring, E28
69		PH.0020205	Gas Hose
70		PH.0020210	Diffuser Ring
71	50501	I30661	Burner Plate
72		M10328	Screw
73	50503	I31132	Coupler, Straight,7,1/8"FF
74	50331	T30217-115	Valve, Solenoid,VE189HV,115V
75		G06451-9010	Pressure Switch Support Bracket
77	50364	E50443	Switch, Pressure,330PA
78	50469	C30374	Drain, Plug
79	50472	E11233	Condenser
80	50118	E10677-110	Motor, 200watt, w/Condenser
81	50484	G06200-9010	Fan, Motor, Support
82	50238	C10328	Snorkel, Air
83	50411	C30372	Protection, Cable
84	50485	G06201-9010	Support, Pan
85	50468	C10329	90° ,Elbow, Connection
86	50333	T10269	Fan
87		C10326	Fan, Spiral
88	50486	G06202	Shutter, for, Air, Regulation
89	50487	G06203	Air, Adjustment, Level
90	50506	I39102	SEAL,3/4"
91	50505	I31205-1	Coupler, Connection,3/4"MM
92	50500	I20326	Coupler, Connection,3/4"FF
97	50739	T30115	Gas, Valve
101	50489	G06227	Motor, Support
102	50516	M20907	Valve, Support, Brackets
103		I31204-1	Fitting
104		T30330-4	Gas Selector Valve
105	50359	T30333	Valve, Manual, Gas, Test, Firing
120	N/A	G06443	Pipe

NEVER LEAVE THE HEATER UNATTENDED WHILE BURNING!

HS4000 IDG



REF#	P/N	ALT#	DESCRIPTION
121		I30859	Connection
122	50234	M20128	Washer ,1/8"X1.5
123	50503	I31132	Coupler, Straight,7,1/8"FF
125		G06452	Pressure Switch Support Bracket
126		G06335-9005	Chassis Support Bracket
127		G06336-9005	Bumper
128		G06337-9005	Base Support Plate
129		G06338-9005	Frame
130	40514	G06208	Reinforcement plate
131	50535	G06209	Fork, Guides
132	40518	G06326-9005	Bracket for Lifting Frame
133		G06420-9005	Wheels Axle support Bracket
134	40521	G06419-9005	Wheel Axle 25 mm
135	40506	C10558	Wheel
136	40533	M20111	Washer
137	40534	M20505	Wheel Locking Pin
138	40524	G06422	Reinforcement Plate
139		G06461-9005	Support
140	40527	G06425-9005	Panel
141	40526	G06424-9005	40526
142	40525	G06423-9005	Handle
143	40505	C10203	Handle
144	40535	M30001	Spring
145	40528	G06426	Plate
146	40507	C10710	Knurled Wheel
147		G06439-9005	Frame
149		G06459	Stirrup
150	50576	E20950	Ring Nut
151	50575	E20949	Cable, Fastener
152	50737	T30116	Regulator
153		E20965	Cable Fastener Nut
154		E20964	Cable Fastener

PARTS ORDERING INFORMATION:

PURCHASING: Accessories may be purchased at any HEAT STAR local dealer or direct from the factory

FOR INFORMATION REGARDING SERVICE

Please call Toll-Free 866-447-2194

- www.heatstarbyenerco.com

Our office hours are 8:00 AM – 5:00 PM, EST, Monday through Friday.

Please include the model number, date of purchase, and description of problem in all communication.